

WOOD REVIVER

IMPORTANT!

Before use, test the Wood Reviver and subsequent products to ensure a satisfactory end result.

PRODUCT DESCRIPTION & AREAS OF USE

A water-based product using natural technology that restores hard and soft woods to their natural tone. Wood Reviver treats greying rough sawn or smooth timber that is UV/weather damaged. Suitable for windows, sheds, fences, decking and outdoor wooden furniture.

PREPARATION: Shake container well before and during use. Wood must be clean and bare before treating. Wood Reviver may remove some existing wood finishes, however if surface coatings remain, use Barretline Paint Panther® or Peelaway® to remove oil, paint, varnish or wax. Do not use a pressure washer to clean wood prior to application of Wood Reviver.

A test area is recommended before wider application. Protect plants as product splashes may cause localised leaf browning. Avoid contact with calcareous stones e.g. limestone/marble as damage may occur. Direct/prolonged application to metal fixings (especially zinc) should be avoided to prevent potential discolouration/ damage. If the product does make contact, rinse thoroughly with water using a damp cloth. Wear protective clothing and keep children and pets away from treated areas until the area has been rinsed.

APPLICATION: Apply in weather conditions between 5-30°C, out of direct sunlight. Before applying the Wood Reviver, wet the wood with water. Apply Wood Reviver generously to all visible sides of wood/panels in the direction of the wood grain using a brush or roller to areas 2m² at a time to prevent the wood from drying out. If the wood does dry, repeat wetting by spraying with water or wipe with a damp cloth to rehydrate. Leave the Wood Reviver to work for 15-30 min. Agitate by rubbing the surface with a cloth or non-metal brush dampened with water. Finally rinse again thoroughly. Repeat the process as necessary. As a precaution against inactive mould spores use Barretline Mould & Mildew Cleaner. Wood restoration and the colour change may not be fully visible until the wood has dried.

Please note: The appearance of the revived wood will vary depending wood type, age and condition. A test area is recommended before wider application. A light sanding may be required to restore a smooth finish.

Coverage: Up to 4m²/L, depending on wood porosity and finish.

AFTERCARE/MAINTENANCE: Allow wood to dry fully (approx. 24 hrs). Depending on the area treated, protect your wood against UV/weather damage by treating with a Barretline Nourish & Protect finish such as: Wood Protective or Preservative Treatment, UV Cladding Protector, UV Decking Oil, Garden Furniture or Teak Oil for outdoor furniture. Lower temperatures/higher humidity can extend the drying time.

Cleaning: Clean brushes/equipment using soap and water or Barretline BioSprit.

Storage: Reseal container, always store upright and secure at all times.

Store between 5-30°C, do not allow product to freeze.

Healthy, Safety & Environmental Information

Warning

Harmful if swallowed or in contact with skin. Keep out of reach of children. Wash hands thoroughly after handling. Do not eat, drink or smoke when using this product. Wear protective gloves/protective clothing/eye protection. IF SWALLOWED: Call a POISON CENTRE or doctor if you feel unwell. IF ON SKIN: Wash with plenty of soap and water. Rinse mouth. Take off contaminated clothing and wash it before reuse. Dispose of contents/container to hazardous or special waste collection point.



UFI: VV10-00UD-C00G-Y6HK



Barretline Products:
St. Ivel Way, Warmley,
Bristol. BS30 8TY. UK
T: +44 (0) 117 9600060
E: sales@barretline.co.uk
www.barretlinePro.co.uk

Barretline (Europe) Ltd:
Unit 3D North Point House,
North Point Business Park,
New Mallow Road, Cork,
T23 AT2P. Ireland.
T: +353 21 206 6530

5 Litre e